



#### Application Note:


WP111 fits SB Ford 260, 289, 302, 351W, 351C, 351 and 400M engines. Correct back plate part # will depend on your engine type.

## Installation Instructions WP111 SB Ford Centrifugal 12V Pump

### In The Box:

- 1 Electric Pump WP111
- 4 5/16-18 x 3.5" Long SSSHCS bolts and washers
- 1 1" NPT Plug
- 2 Flange Gaskets WPG111
- 1 Wiring harness w/ 20 amp fuse
- 2 Contingency Decals

*The inlet fitting must be ordered separately to match your lower radiator hose type and size.*



### To Do the Job You Will Need:

- Scraper or wire brush
- Brake Cleaner
- Sealant; Form-a-gasket (Aviation), Form-A-Gasket 2 (Non-Hardening), Gaskacinch or RTV silicone
- Thread sealant; RTV silicone or liquid pipe thread sealant
- 1/4" hex socket
- 1/2 drive ratchet
- Spanner wrench

### Mounting the Back Plate:

Remove stock water pump, clean and degrease the gasket surface. Apply sealant to both sides of factory gasket and tack to the backside of the Meziere back plate (WP112, WP113 or WP123). Align gasket to bolt holes and bolt to timing cover using 5/16"-18 hardware provided.

### Mounting the Pump:

Be sure to use a proper sealant on both sides of the mounting flange gaskets. Bolt pump in place using 5/16"-18 x 3.5" hardware provided. Tighten all four bolts to the recommended 15 ft./lbs.

### Inlet:

Our hose inlets are designed to be tightened using a spanner wrench. We understand that not every mechanic owns a spanner wrench. The job can be done using a pair of drill bits placed in the spanner holes and a screwdriver bridged across the drill bits (see photo on the right). **It is necessary to use a small amount of RTV silicone or liquid pipe thread sealant on the 1" pipe threads of the inlet and plug.**



### Wiring the Pump:

Use the fused harness supplied with the pump.

The **BLUE** wire should be connected to a 12 volt positive (+) switched source.

The **BLACK** wire should be connected to ground.

Supply and ground wires should be 14 gauge minimum. All switches should be rated at 20 amps or better.

**WARNING: Not using a protection circuit (Fused circuit) will void your warranty.**

### Startup / Running:

Fill the cooling system. Replace fill cap and turn on pump. Remove fill cap and top off coolant level. Recheck level after one heat cycle. **DO NOT RUN PUMP DRY for more than a few seconds.**

### Beauty Tip:

Your pump comes to you polished and waxed. Occasional waxing will allow dirt or debris to be wiped right off the pump and offer some protection from UV light (the anodized color on your pump can fade from prolonged exposure to sunlight).

California Proposition 65 Warning: Please see reverse side for Prop 65 information.

**Meziere Enterprises 220 S. Hale Ave. Escondido, CA 92029 760-746-3273**

California Proposition 65 Warning

**WARNING: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.**

**WARNING:** Motor vehicles contain fuel, oils and fluids, battery posts, terminals and related accessories which contain lead and lead compounds and other chemicals known to the State of California to cause cancer, birth defects and other reproductive harm. These chemicals are found in vehicles, vehicle parts and accessories, both new and as replacements. When being serviced, these vehicles generate used oil, waste fluids, grease, fumes and particulates, all known to the State of California to cause cancer, birth defects, and reproductive harm.

For background on the new Proposition 65 warnings, see:  
<https://www.p65warnings.ca.gov/new-proposition-65-warnings>

Proposition 65 and its regulations are posted at:  
<https://oehha.ca.gov/proposition-65/law/proposition-65-law-and-regulations>

To give Meziere notice of an alleged violation of California Health and Safety Code Section 25249.5 or 25249.6, you must send notice to:  
[meziere@meziere.com](mailto:meziere@meziere.com)